

Floorplans



Typical Core and Shell Plan
Floor 2
14,666 RSF



222 Broadway



Contact: David C. Berkey
Executive Vice President
David.Berkey@LL-Holding.com
(212) 920-3388


Andrew Wiener
Director of Leasing
Andrew.Wiener@ll-holding.com
(646) 341-9838



NORTH

Prepared By PlanData Systems Corp.
All areas and dimensions are approximate.
Field verification is necessary

Typical Core and Shell Plan
Floor 3
39,580 RSF



222 Broadway




Contact: David C. Berkey
Executive Vice President
David.Berkey@LL-Holding.com
(212) 920-3388

Andrew Wiener
Director of Leasing
Andrew.Wiener@ll-holding.com
(646) 341-9838



Prepared By PlanData Systems Corp.
All areas and dimensions are approximate.
Field verification is necessary

Typical Core and Shell Plan
 Floor 4
 39,461 RSF



222 Broadway




Contact: David C. Berkey
 Executive Vice President
 David.Berkey@LL-Holding.com
 (212) 920-3388

Andrew Wiener
 Director of Leasing
 Andrew.Wiener@ll-holding.com
 (646) 341-9838



Prepared By PlanData Systems Corp.
 All areas and dimensions are approximate.
 Field verification is necessary

Typical Core and Shell Plan
 Floor 5
 39,576 RSF



222 Broadway




Contact: David C. Berkey
 Executive Vice President
 David.Berkey@LL-Holding.com
 (212) 920-3388

Andrew Wiener
 Director of Leasing
 Andrew.Wiener@ll-holding.com
 (646) 341-9838



Prepared By PlanData Systems Corp.
 All areas and dimensions are approximate.
 Field verification is necessary

Typical Core and Shell Plan
 Floor 6
 39,287 RSF



222 Broadway



Contact: David C. Berkey
 Executive Vice President
 David.Berkey@LL-Holding.com
 (212) 920-3388


Andrew Wiener
 Director of Leasing
 Andrew.Wiener@ll-holding.com
 (646) 341-9838



NORTH

Prepared By PlanData Systems Corp.
 All areas and dimensions are approximate.
 Field verification is necessary

Typical Core and Shell Plan
 Floor 7
 39,443 RSF



222 Broadway




Contact: David C. Berkey
 Executive Vice President
 David.Berkey@LL-Holding.com
 (212) 920-3388

Andrew Wiener
 Director of Leasing
 Andrew.Wiener@ll-holding.com
 (646) 341-9838



Prepared By PlanData Systems Corp.
 All areas and dimensions are approximate.
 Field verification is necessary

Typical Core and Shell Plan
 Floor 8
 39,116 RSF



222 Broadway




Contact: David C. Berkey
 Executive Vice President
 David.Berkey@LL-Holding.com
 (212) 920-3388

Andrew Wiener
 Director of Leasing
 Andrew.Wiener@ll-holding.com
 (646) 341-9838



Prepared By PlanData Systems Corp.
 All areas and dimensions are approximate.
 Field verification is necessary

Typical Core and Shell Plan
 Floor 9
 39,088 RSF



222 Broadway




Contact: David C. Berkey
 Executive Vice President
 David.Berkey@LL-Holding.com
 (212) 920-3388

Andrew Wiener
 Director of Leasing
 Andrew.Wiener@ll-holding.com
 (646) 341-9838



Prepared By PlanData Systems Corp.
 All areas and dimensions are approximate.
 Field verification is necessary

Typical Core and Shell Plan
 Floor 10
 36,553 RSF



222 Broadway




Contact: David C. Berkey
 Executive Vice President
 David.Berkey@LL-Holding.com
 (212) 920-3388

Andrew Wiener
 Director of Leasing
 Andrew.Wiener@ll-holding.com
 (646) 341-9838



Prepared By PlanData Systems Corp.
 All areas and dimensions are approximate.
 Field verification is necessary

Typical Core and Shell Plan
 Floor 11
 37,580 RSF



222 Broadway



Contact: David C. Berkey
 Executive Vice President
 David.Berkey@LL-Holding.com
 (212) 920-3388


Andrew Wiener
 Director of Leasing
 Andrew.Wiener@ll-holding.com
 (646) 341-9838



NORTH

Prepared By PlanData Systems Corp.
 All areas and dimensions are approximate.
 Field verification is necessary

Typical Core and Shell Plan
 Floor 12
 35,999 RSF



222 Broadway




Contact: David C. Berkey
 Executive Vice President
 David.Berkey@LL-Holding.com
 (212) 920-3388

Andrew Wiener
 Director of Leasing
 Andrew.Wiener@ll-holding.com
 (646) 341-9838



Prepared By PlanData Systems Corp.
 All areas and dimensions are approximate.
 Field verification is necessary

Typical Core and Shell Plan
Floor 13
36,344 RSF



222 Broadway



Contact: David C. Berkey
Executive Vice President
David.Berkey@LL-Holding.com
(212) 920-3388


Andrew Wiener
Director of Leasing
Andrew.Wiener@ll-holding.com
(646) 341-9838



NORTH

Prepared By PlanData Systems Corp.
All areas and dimensions are approximate.
Field verification is necessary

Typical Core and Shell Plan
 Floor 14
 36,344 RSF



222 Broadway



Contact: David C. Berkey
 Executive Vice President
 David.Berkey@LL-Holding.com
 (212) 920-3388

Andrew Wiener
 Director of Leasing
 Andrew.Wiener@ll-holding.com
 (646) 341-9838



NORTH

Prepared By PlanData Systems Corp.
 All areas and dimensions are approximate.
 Field verification is necessary